



### Quick Detach Saddlebag Brackets

Visit [www.greatbikegear.com](http://www.greatbikegear.com) to view installation video

**KEY CODE NUMBER** \_\_\_\_\_  
(Save this number for future key identification)

### Applications

BMWR18 – **Model R18**  
2020 BMW R18

Before you begin, read these instructions and check to be sure all parts are accounted for.

<u>Qty.</u>	<u>Part Description</u>
2	Easy Brackets (ID number 01, stamped on brackets)
2	8MM Docking Post, front
2	8MM Docking Post, rear
4	8MM Polished SS Socket Head Bolt
8	3/8 x 1 SS Button Head Bolt
8	3/8 Nylon Locking Nuts
8	3/8 Fender Washers
2	Keys

### Installation Instructions

1. Remove the bolts on the right side of the motorcycle. Remove one bolt at a time. Replace the rear bolt with the long docking post and bolt. Reuse the rubber grommet and spacer. Repeat with the short docking post at the front..
2. Repeat step 1 on the LH side of the fender.
3. Install the EASY BRACKETS on the docking posts. **Note:** Use the key provided to open the cam lock prior to installation on the docking posts. The key can not be removed until the cam lock is fully engaged under the docking post.
4. Hold the RH saddlebag against the EASY BRACKET. Position the saddlebag as desired noting the clearances from the seat, turn signals and any lower obstructions such as chain guards, axle nuts, and etc. Mark the outer edge of the bracket on the saddlebag. Remove the EASY BRACKET from the motorcycle.
5. Place the bracket on the saddlebag within the outline and drill the 4 holes for mounting. Attach the bracket to the saddlebag using the (4) 3/8 x 1 SS button head bolts, (4) 3/8 fender washers and (4) 3/8 Nylon locking nuts (**All 4 mounting points MUST be utilized**). Install the completed RH saddlebag with EASY BRACKETS on the motorcycle. **Note: The cam lock must be fully engaged and the key removed to ensure the EASY BRACKETS are properly installed and ready for use.**
6. Repeat steps 4, 5, and 6 on the LH side of the fender.


### Notice to Consumer

**Do not exceed 15 lbs. of total weight on the EASY BRACKET saddlebag removal system.**


Neither the manufacturer nor the distributor nor retailer of the EASY BRACKETS makes any express warranties of any kind with respect to the EASY BRACKETS. Any implied warranty does not cover defects caused by modification or alterations of the EASY BRACKETS or caused by physical abuse to or misuse of the EASY BRACKETS or its use and/or operation in a manner contrary to the accompanying instructions. Failure to install and/or use the EASY BRACKETS in the manner described by the accompanying instructions shall render all warranties, expressed and/or implied, void and release the manufacturer, distributor and retailer from any and all liability arising from the use of the EASY BRACKETS.

**For product support, damaged or missing parts, please contact Great Bike Gear at 866-521-3024**  
**Do not return product without prior authorization.**


**SEE REVERSE SIDE FOR ILLUSTRATIONS**




TYP BOLT/DOCKING POST



DETAIL A



DETAIL B



TYPICAL DETAILS